

HOW TO ATTACH BLADES TO SPREADER HANDLES

To attach handles to blades, we suggest you use a 6 minute Gel Epoxy. Apply epoxy to areas shown and set aside. You will need to place the piece so that the blade is held in the correct position for about 6 minutes. The epoxy will fully cure in about 4 hours.



Apply Gel Epoxy to these locations.

gare[®]

phone 1.888.289.4273 x.17 fax 1.800.292.0885 email: srogers@gare.com www.gare.com