

Organic Ware Pottery Glazes

Recipe Courtesy of Gare, Inc.

Ingredients

Bisque

- # 2139 Organic Ware Bowl
- # 1073 Organic Ware Salad Plate
- # 1074 Organic Ware Dinner Plate
- # 1075 Organic Ware Charger/Platter

Color

- SC-2600 White Board Surface Coat
- NTG-9522 Ocean Mist
- NTG-9516 Midnight Stone

Brushes and Other Materials

- # 6571 Aqualon™ Soft Fan Brush
- # 6570 Aqualon™ Goat Mop Brush

Instructions (Read all instructions before you begin)

Step 1- Using a soft fan brush, cover the front and back of all pieces in 3 coats of White Board and let dry.

Step 2- Apply two coats of Ocean Mist to the top side of each piece (inside of bowl) with a mop brush, stopping about ¼" from the edge as shown in photo.

Step 3- Apply two coats of Midnight Stone on top of the Ocean Mist using the exact same application instructions as in Step 2.

NOTE: The thicker the coats of pottery glaze are applied, the deeper the fired color will be, so variations in glaze thickness will cause variations to the color of the fired piece.

Step 4- Fire to a cone 06.



gare®

phone 1.888.289.4273

fax 1.800.292.0885

www.gare.com